





REFER TO: WWW.CARNUT.INFO FOR DETAILS

**CAUTION!**  
DO NOT SHORT TRACKS ON TOP WITH SOLDERING IRON

BOTTOM

REFER TO MEB