

# tinySA MENU STRUCTURE

TOUCH THE SCREEN

SWEEP  
DISPLAY  
STORAGE  
OUTPUT  
SAVE/RECALL  
CONFIG

SWEEP START  
SWEEP STOP  
SWEEP CENTRE  
SWEEP SPAN  
FOCUS FREQ.  
MORE ->  
<-BACK

RBW  
ATTEN  
MARKERS  
<-BACK

TRACES  
PREAMP GAIN  
REF LEVEL  
dB/DIV  
SPUR REDUCE  
DEFAULT SETTINGS  
<-BACK

STORE  
CLEAR  
SUBTRACT  
<-BACK

REFERENCE  
GENERATOR  
<-BACK

SAVE  
RECALL  
<-BACK

RECALL 0 SAVE 0  
RECALL 1 SAVE 1  
RECALL 2 SAVE 2  
RECALL 3 SAVE 3  
RECALL 4 SAVE 4

CALIBRATE  
TOUCH SCREEN  
IF FREQ.  
SAVE CONFIG  
VERSION  
<-BACK

TX FREQ  
RX FREQ  
ACTUAL POWER

TOUCH CAL  
TOUCH TEST  
<-BACK

KEYPAD

TGL MARKER 1  
TGL MARKER 2  
TGL MARKER 3  
TGL MARKER 4  
ENABLE ALL  
DISABLE ALL  
<-BACK

AUTO  
3kHz  
10kHz  
30kHz  
100kHz  
300kHz  
<-BACK

AGC ON  
SET VALUE  
<-BACK

dB On/Off  
GAIN On/Off  
AVERAGE  
<-BACK

KEYPAD  
1dB  
2dB  
5dB  
10dB  
20dB  
<-BACK

OFF  
ON  
<-BACK

OFF  
ON  
<-BACK

3MHz  
2MHz  
1MHz  
<-BACK