




These signals also available on







These signals also available on 10-way connector on bottom of PCB.





Extra Butler Heater Regulator (option):
Fit R101A Omit R101 Fit IC1X



Plug matrix
See text.
DSP S-Meter

Analogue 'S' Meter (option)
Select Polarity (Fit One Only)
Adjust FSD

Meter





See Recommended Modification (Ver. A Pcb)

Remote Console LEDs (option)
'S' Meter Programmer (option)

Local or Remote Keypad

PSU 12V



Main Control Programmer (option)



No
1/ F
to P
2/ 1
buil
3/ 1
4/ 1
5/ 1
ont
6/ 1
But
7/ 1
ad